

The **BASH!**

2133 Mountain Industrial Blvd
Tucker, GA 30084
BashPartyRentals@gmail.com

Phone – (404) 437-6136

www.BashPartyRentals.com

Sno-Cone Machine

***We recommend that the sno-cone machine be plugged directly into a dedicated outlet.
Extension cords may create a safety hazard and reduce performance.***

Instructions for Use:

1. Plug drain hose into base of the unit on one end and place the other end into a bucket.
2. Turn POWER switch ON.
3. Fill the ice horn with ice.
4. Press and hold the MOTOR switch to activate blades and begin shaving ice.
5. While holding MOTOR switch down, apply steady downward pressure to the handle.
6. Release the MOTOR switch when finished.
7. Repeat steps 2-5 for additional batches.

CAUTION: BLADES ARE SHARP AND OPERATE AT HIGH SPEEDS!

Please be sure to keep all body parts and any objects such as picks or scoops away from the ice horn while POWER is on!

Inventory List:

- 1 – Sno-Cone Cart
- 1 – Sno-Cone Shaver -Main Unit
- 1 – Drain Hose
- 1 – Plastic ice storage tray (inside of main unit)
- 1 – Clear Plexiglas Cup Dispenser
- 1 – Scoop